

DIRECTIONS FOR THE USE OF Sheaffer's Self-Filling Fountain Pen



Sectional view No. 2, showing ink reservoir compressed.



A Sectional view No. 1, showing point in airtight chamber.

Proper Way to Fill

Improper Way to Fill




Illustration No. 1




Illustration No. 2

FILLING FOUNTAIN PENS

Illustration No. 1 shows proper method to fill a fountain pen. Entirely submerge Pen Point to Letter A, then snap lever shut and leave in ink five seconds. Release lever and pen will fill.

Illustration No. 2 shows improper method to fill fountain pen. Pen Point to letter B being partly submerged is filling pen with air. To properly fill follow Illustration No. 1.

When filling pen the first time, fill and expel ink several times to thoroughly moisten feed and gold pen point.

Free from Sediment—"Skrip" Successor to Ink—
Eliminates Fountain Pen Trouble—Ask your dealer.
The cause of most fountain pen trouble—Muddy
and Gummy Inks.

SHEAFFER pens are assembled and adjusted by fountain pen experts and we cannot guarantee satisfaction if they are taken apart or altered in any way. When a new gold pen or any repairs are needed take the complete pen to your SHEAFFER dealer, or mail it to us, so that the new parts can be properly and perfectly fitted together.


Always mark your name and address plainly on the package so that we can identify it in connection with your letter of instructions. Always send remittance to cover cost of new parts and also include return postage.

Gold pens can be repointed or straightened for 50 cents each. Repointed pens cannot be warranted to wear as well as new nor have the same quality of point as new pens. We do not recommend repointing pens smaller than No. 5.

W. A. SHEAFFER PEN CO., Fort Madison, Ia., U. S. A.

DIRECTIONS FOR USING THE SHEAFFER "Propel-Repel-Expel" PENCIL

Just "turn the top" to operate this pencil. A quarter turn to the right propels the lead forward into writing position. A quarter turn to the left brings the lead back into the barrel. A few turns to the right ejects the lead to its full length and the metal push wire goes clear to the tip so that the lead drops out.



TO INSERT NEW LEADS: First be sure to turn the cap "A" to the left just as far as it will go. Then pull out cap "A" and remove eraser cup "C" from magazine "B." Take out a new lead and replace eraser cup and cap in barrel. Insert new lead into the tip of the barrel at "D." It will go in very easily two-thirds of the way. Then you will meet with a slight resistance. The lead is entering the lead carrier. Keep pushing firmly until a solid resistance is met, in order to properly engage the lead in the carrier. If the lead is full length, the point will be projecting about $\frac{1}{4}$ of an inch, which is the proper writing length. Keep the lead always at about this length—when longer it is easily broken.

IMPORTANT

In refilling Sheaffer's "Propel-Repel-Expel" Pencils turn cap (Point A) to right until every particle of lead is expelled at point D. Be positive and see if the Ejector or Repel Metal push wire shows at point (D) coming through carrier and until the ejector point can be seen the carrier still is occupied by a small particle of lead and it is impossible to insert a lead into the carrier until every particle is ejected. Be positive that Ejector Point shows through carrier before Refilling. This assures lead holding in carrier when refilled.

"PROPEL-REPEL-EXPEL" FEATURES

The repel feature of the Sheaffer Pencil eliminates possibility of soiling men's shirts, ladies' waists and inside of ladies' hand bags.

The symmetrical lines embodied in its construction, its patented bell shaped cap together with its patented clip eliminates wear and tear on pockets make it the most practical pencil in use.

The mechanism inserted into barrel under 30 pound pressure eliminates solder and prevents loose mechanisms.

Under size as well as over size leads that continuously cause jamming and trouble in ordinary pencils hold firmly and rigid thereby allowing full writing comforts.

USE SHEAFFER LEADS AND ERASERS

Whenever necessary to buy a new supply of Leads insist upon Sheaffer's Blue Label Leads in all colors. Priced, Black, box of 12, 10c; Indelible, box of 12, 15c; Red and Blue Leads, packed 8 to a box priced at 15c. They insure better writing qualities.

Sheaffer Leads are made of finest material, will not break and are furnished in three grades hard, soft and medium.

Sheaffer erasers packed in boxes of three, with cup attached, ready for insertion in barrel. Priced 5c each.

W. A. SHEAFFER PEN CO., Fort Madison, Ia.

New York Chicago Denver San Francisco
370 Seventh Ave. 506 Republic Bldg. 502 Jacobson Bldg. 681 Market St.